

Производитель	Модель
Acer	beTouch E100
Acer	beTouch E101
Acer	beTouch E140
Acer	beTouch E200
Acer	DX650
Acer	ICONIA SMART
Acer	Liquid
Acer	Liquid E Ferrari
Acer	Liquid Metal
Acer	Liquid Mini
Acer	neoTouch
Acer	Tempo DX900
Acer	Tempo F900
Acer	Tempo M900
Acer	Tempo X960
Alcatel	OT-980
AnexTEK	moboDA 3360
AnyDATA	ASP-500GA
AnyDATA	ASP-505A
Apple	iPad
Apple	iPhone
Apple	iPhone 3G
Apple	iPhone 3GS
Apple	iPhone 4
Apple	iPhone 4S
Apple	iPhone 8Gb
ASUS	M530w
ASUS	M930
ASUS	P320
ASUS	P525
ASUS	P526
ASUS	P527
ASUS	P535
ASUS	P550
ASUS	P552w
ASUS	P565
ASUS	P750
ASUS	P835
BenQ-Siemens	P51
Dopod	818 Pro
Dopod	U1000
Eten	G500
Eten	Glofiish DX900
Eten	Glofiish M700
Eten	Glofiish M750
Eten	Glofiish M800
Eten	Glofiish M810
Eten	Glofiish V900
Eten	Glofiish X500
Eten	Glofiish X500+
Eten	Glofiish X600
Eten	Glofiish X610

Производитель	Модель
Eten	Glofish X650
Eten	Glofish X800
Eten	Glofish X900
Eten	M600
Eten	M600+
Fly	IQ-110
Fly	IQ-120
Fly	PC100
Fly	PC200
Fujitsu-Siemens	Pocket LOOX T810
Fujitsu-Siemens	Pocket LOOX T830
Garmin-Asus	A10
Garmin-Asus	nuvifone A50
Garmin-Asus	nuvifone M10
Garmin-Asus	nuvifone M20
GigaByte	g-Smart
GigaByte	g-Smart i
GigaByte	g-Smart i128
GigaByte	GSmart G1305
GigaByte	GSmart i120
GigaByte	GSmart i300
GigaByte	GSmart i350
GigaByte	GSmart MS800
GigaByte	GSmart MS802
GigaByte	GSmart MS820
GigaByte	GSmart MW702
GigaByte	GSmart MW720
GigaByte	GSmart MW998
GigaByte	GSmart q60
GigaByte	GSmart S1200
GigaByte	GSmart S1205
GigaByte	GSmart t600
Google	Nexus One
Google	Nexus S
Gresso	Avantgarde Luna Gold
Gresso	Avantgarde Luna Steel
Gresso	Avantgarde Skeleton
Gresso	Avantgarde Sol Gold
Gresso	Avantgarde Sol Steel
Gresso	Black Diamonds
Gresso	Gresso Skeleton Ultramarine Gold
Gresso	Lady Diamond
Gresso	Lady Gold
Gresso	Royal Black Diamonds
Gresso	Royal White Diamonds
Gresso	Skeleton Gold
Gresso	White Diamonds
Haier	A610
HP	iPAQ 514 Voice Messenger
HP	iPAQ 614 Business Navigator
HP	iPAQ 614c Business Navigator
HP	iPAQ 914c Business Messenger

Производитель	Модель
HP	iPAQ Data Messenger
HP	iPAQ hw6710
HP	iPAQ hw6715
HP	iPAQ hw6910
HP	iPAQ hw6915
HP	iPAQ hw6940
HP	iPAQ rw6815
HP	iPAQ Voice Messenger
HTC	4G
HTC	Aria
HTC	Desire
HTC	Desire HD
HTC	Desire S
HTC	Desire Z
HTC	Diamond2
HTC	Droid Incredible
HTC	EVO 3D
HTC	EVO 4G
HTC	Gratia
HTC	HD mini
HTC	HD2
HTC	Hero
HTC	Hero (HERO110)
HTC	Hero (HERO120)
HTC	Hero (HERO130)
HTC	HTC Touch2
HTC	Imagio
HTC	Incredible S
HTC	Legend
HTC	Magic
HTC	Magic (SAPP200)
HTC	Magic (SAPP300)
HTC	Magic (SAPP310)
HTC	Magic (SAPP500)
HTC	MAX 4G
HTC	MTeoR
HTC	Nexus One
HTC	Ozone
HTC	P3300
HTC	P3350
HTC	P3470
HTC	P3600
HTC	P4350
HTC	P6300
HTC	P6500
HTC	Pure
HTC	S310
HTC	S420
HTC	S620
HTC	S710
HTC	S730
HTC	S740

Производитель	Модель
HTC	Salsa
HTC	Sensation
HTC	Snap
HTC	T-Mobile G1
HTC	Tattoo
HTC	Tattoo
HTC	Touch 3G
HTC	Touch Cruise II T4242
HTC	Touch Cruise P3650
HTC	Touch Diamond
HTC	Touch Diamond CDMA
HTC	Touch Diamond P3490
HTC	Touch Diamond P3700
HTC	Touch Diamond2
HTC	Touch Dual
HTC	Touch HD
HTC	Touch P3450
HTC	Touch P3452
HTC	Touch Pro
HTC	Touch Pro CDMA
HTC	Touch Pro2
HTC	Touch Viva
HTC	TyTN
HTC	TyTN II
HTC	TyTN Pro
HTC	Wildfire
HTC	X7500
HTC	X7510
Huawei	Ideos U8150
Huawei	IDEOS X5
Huawei	U8230
Huawei	U8500
i-Mate	JAMA
i-Mate	JAMA 101
i-Mate	JAMA 201
i-Mate	JAMin
i-Mate	JAQ3
i-Mate	JASJAM
i-Mate	JASJAR
i-Mate	K-JAM
i-Mate	SmartFlip
i-Mate	SP5
i-Mate	SP5m
i-Mate	SPJAS
i-Mate	Ultimate 5150
i-Mate	Ultimate 6150
i-Mate	Ultimate 7150
i-Mate	Ultimate 8150
i-Mate	Ultimate 8502
i-Mate	Ultimate 9150
i-Mate	Ultimate 9502
Kyocera	Zio M6000

Производитель	Модель
Lenovo	ET980
LG	E720 Optimus Chic
LG	GM730
LG	GM750
LG	GT540 Optimus
LG	GW620
LG	KS20
LG	Optimus 2X
LG	Optimus 3D P920
LG	Optimus Black
LG	Optimus Me P350
LG	P500 Optimus One
LG	T300
Mitac	Mio A501
Mitac	Mio A502
Mitac	Mio A700
Mitac	Mio A701
Mitac	Mio A702
Mitac	Mio Explora K70
Mitac	Mio Leap G50
Motorola	Atrix 4G
Motorola	Aura
Motorola	BACKFLIP
Motorola	Defy
Motorola	DEVOUR
Motorola	Dext
Motorola	Droid
Motorola	DROID Pro
Motorola	Droid X
Motorola	E1070
Motorola	Evoke QA4
Motorola	Milestone
Motorola	Milestone 2
Motorola	MOTO Q 9h
Motorola	MOTO U9
Motorola	MOTOKRZR K3
Motorola	MOTORAZR Z3
Motorola	MOTOSURF A3100
Motorola	MotoZINE ZN5
Motorola	Q
Motorola	Q q9h
Motorola	Quench
Motorola	RAZR2 V8
Motorola	RAZR2 V9
Motorola	RIZR Z3
Motorola	ROKR E2
Motorola	ROKR E6
Motorola	ROKR Z6
Motorola	SLVR L9
Motorola	W215
Motorola	W218
Motorola	W230

Производитель	Модель
Motorola	W270
Motorola	W375
Motorola	W510
Motorola	W7
Motorola	Z9
Motorola	ZN300
MTC	1055
MTC	535
MTC	540
MTC	635
MTC	655
MTC	733
MTC	752
MTC	835
MTC	840
MTC	916
MTC	945
MTC	950
MTC	955
NeoNode	N2
Nokia	2220 slide
Nokia	2320 classic
Nokia	2323
Nokia	2330 Classic
Nokia	2680 slide
Nokia	2690
Nokia	2700 Classic
Nokia	2710 classic
Nokia	2720 fold
Nokia	2730 classic
Nokia	2865
Nokia	2865i
Nokia	3109 Classic
Nokia	3110 Classic
Nokia	3120 Classic
Nokia	3155i
Nokia	3208 classic
Nokia	3500 Classic
Nokia	3555
Nokia	3600 slide
Nokia	3610fold
Nokia	3710 fold
Nokia	3720 classic
Nokia	5000
Nokia	5070
Nokia	5130
Nokia	5130 XpressMusic
Nokia	5130classic
Nokia	5200
Nokia	5220
Nokia	5228
Nokia	5230

Производитель	Модель
Nokia	5233
Nokia	5250
Nokia	5300
Nokia	5310 XpressMusic
Nokia	5310b XpressMusic
Nokia	5320
Nokia	5330
Nokia	5530 XpressMusic
Nokia	5610 XpressMusic
Nokia	5630 XpressMusic
Nokia	5730 XpressMusic
Nokia	5800 XpressMusic
Nokia	5800b XpressMusic
Nokia	5800i XpressMusic
Nokia	6111
Nokia	6125
Nokia	6126
Nokia	6131
Nokia	6136
Nokia	6151
Nokia	6152
Nokia	6155
Nokia	6155i
Nokia	6165
Nokia	6208classic
Nokia	6210 Navigator
Nokia	6216
Nokia	6220 Classic
Nokia	6233
Nokia	6234
Nokia	6265
Nokia	6265i
Nokia	6267
Nokia	6270
Nokia	6275
Nokia	6275i
Nokia	6280
Nokia	6282
Nokia	6288
Nokia	6300
Nokia	6300b
Nokia	6300i
Nokia	6301
Nokia	6303i classic
Nokia	6350fold
Nokia	6500 Classic
Nokia	6500 Slide
Nokia	6555
Nokia	6600
Nokia	6600 Fold
Nokia	6600 Slide
Nokia	6600islide

Производитель	Модель
Nokia	6630
Nokia	6650fold
Nokia	6680
Nokia	6700 classic
Nokia	6700 slide
Nokia	6710 Navigator
Nokia	6720 Classic
Nokia	6730 Classic
Nokia	6750
Nokia	6760 Slide
Nokia	6790 slide
Nokia	6790 surge
Nokia	7100 Supernova
Nokia	7200
Nokia	7210 Supernova
Nokia	7230
Nokia	7250
Nokia	7260
Nokia	7360
Nokia	7373
Nokia	7390
Nokia	7500 Prism
Nokia	7510 Supernova
Nokia	7610 Supernova
Nokia	7900 Prism
Nokia	8600 Luna
Nokia	8800 Arte
Nokia	8800 Carbon Arte
Nokia	8800 Gold Arte
Nokia	8800 Sirocco Edition
Nokia	C1
Nokia	C3
Nokia	C3-01
Nokia	C5-00
Nokia	C6-00
Nokia	E5-00
Nokia	E5-00
Nokia	E52
Nokia	E55
Nokia	E71x
Nokia	E72
Nokia	E75
Nokia	E90
Nokia	N72
Nokia	N78
Nokia	N79
Nokia	N85
Nokia	N86 8MP
Nokia	N96-3
Nokia	N97
Nokia	N97mini
Nokia	Nokia 5330 XpressMusic

Производитель	Модель
Nokia	X2-00
Nokia	X3-00
Nokia	X3-02
Nokia	X6-00
Nokia	X6m
O2	Cocoon
O2	Graphite
O2	XDA Atom
O2	XDA Atom Exec
O2	Xda Comet
O2	Xda Cosmo
O2	XDA Flame
O2	XDA mini S
O2	XDA NEO
O2	XDA Nova
O2	Xda orbit
O2	Xda Terra
O2	Xda Zinc
ORSiO	g735
ORSiO	n725
ORSiO	n725 Basic
ORSiO	n725 GPS
ORSiO	p745
Palm	Treo 500
Palm	Treo 750
Qtek	8300
Qtek	8310
Qtek	8500
Qtek	8600
Qtek	9000
Qtek	9100
Qtek	9600
Qtek	S200
Qtek	S300
Rover	PC C6
Rover	PC C7
Rover	PC E5
Rover	PC Evo V7
Rover	PC Evo X8
Rover	PC Q6
Rover	PC Q7
Rover	PC R5
Rover	PC S5
Rover	PC S6
Rover	PC S7
Rover	PC S8
Rover	PC S8 Lite
Rover	PC W5
Rover	PC X7
Samsung	B7350 Witu Pro
Samsung	B7610 Louvre
Samsung	Galaxy Ace

Производитель	Модель
Samsung	Galaxy Gio
Samsung	Galaxy Mini
Samsung	galaxy s
Samsung	Galaxy S II
Samsung	GT-B7300 Omnia LITE
Samsung	GT-B7330
Samsung	GT-B7610
Samsung	GT-B7620 Giorgio Armani
Samsung	GT-C6620
Samsung	GT-C6625
Samsung	GT-I5500
Samsung	GT-i5700 Galaxy Spica
Samsung	GT-I5800 Galaxy 580
Samsung	GT-i7500
Samsung	GT-I8000
Samsung	GT-I9000
Samsung	GT-S3310
Samsung	GT-S5230
Samsung	GT-S8000
Samsung	GT-S8300
Samsung	s3310
Samsung	s5600
Samsung	S5670 Galaxy Fit
Samsung	Samsung SGH-i320
Samsung	SCH-i760
Samsung	SCH-i910
Samsung	SCH-i920
Samsung	SCH-M490
Samsung	SCH-M495
Samsung	SCH-M710
Samsung	SCH-M715
Samsung	SCH-M720
Samsung	SGH-480 La Fleur
Samsung	SGH-F480
Samsung	SGH-G400
Samsung	SGH-i200
Samsung	SGH-i310
Samsung	SGH-i600
Samsung	SGH-i617
Samsung	SGH-i627
Samsung	SGH-i637
Samsung	SGH-i710
Samsung	SGH-i718
Samsung	SGH-i740
Samsung	SGH-i760
Samsung	SGH-i780
Samsung	SGH-i900 16Gb
Samsung	SGH-i900 8Gb
Samsung	SGH-i907 Epix
Samsung	SPH-i325
Samsung	SPH-i350
Samsung	SPH-M7350

Производитель	Модель
Samsung	SPH-M8400
Sharp	W-ZERO3
Sitronics	SDC-106
Sitronics	SSP-101
SonyEricsson	Aspen
SonyEricsson	Aspen White Paper
SonyEricsson	C510i
SonyEricsson	C702i
SonyEricsson	C901
SonyEricsson	C902i
SonyEricsson	C905i
SonyEricsson	F305
SonyEricsson	G502
SonyEricsson	G705i
SonyEricsson	j10i2
SonyEricsson	K310i
SonyEricsson	K320i
SonyEricsson	K500i
SonyEricsson	K530i
SonyEricsson	K550i
SonyEricsson	K610i
SonyEricsson	K750i
SonyEricsson	K770i
SonyEricsson	K790a
SonyEricsson	K790c
SonyEricsson	K790i
SonyEricsson	K800i
SonyEricsson	K810i
SonyEricsson	K850i
SonyEricsson	S500i
SonyEricsson	T650i
SonyEricsson	T700
SonyEricsson	W200i
SonyEricsson	W300i
SonyEricsson	W380i
SonyEricsson	W508
SonyEricsson	W550i
SonyEricsson	W580i
SonyEricsson	W610i
SonyEricsson	W660i
SonyEricsson	W700i
SonyEricsson	W710i
SonyEricsson	W760i
SonyEricsson	W800i
SonyEricsson	W810i
SonyEricsson	W850i
SonyEricsson	W880i
SonyEricsson	W890i
SonyEricsson	W910i
SonyEricsson	W980i
SonyEricsson	W995i
SonyEricsson	Xperia active

Производитель	Модель
SonyEricsson	Xperia arc
SonyEricsson	Xperia Neo
SonyEricsson	Xperia Play
SonyEricsson	Xperia ray
SonyEricsson	XPERIA X1
SonyEricsson	XPERIA X10
SonyEricsson	Xperia X10 mini
SonyEricsson	Xperia X10 mini pro
SonyEricsson	XPERIA X2
SonyEricsson	Xperia X8
SonyEricsson	Z530i
SonyEricsson	Z550i
SonyEricsson	Z610i
SonyEricsson	Z710i
SonyEricsson	Z770i
T-Mobile	Ameo
T-Mobile	MDA compact II
T-Mobile	MDA Pro
T-Mobile	MDA Vario
Toshiba	G500
Toshiba	Portege G710
Toshiba	Portege G810
Toshiba	Portege G900
Toshiba	Portege G910
Toshiba	TG01
Vobis	HIGHSCREEN PP5420
Vobis	Highscreen Zeus
Voxtel	W210
Voxtel	W420
Voxtel	W520
Voxtel	W740