

Производитель	Модель
DMTECH	LV19XVM
Finlux	37flhd 760-tc/37"
Grundig	SX(32)
Grundig	Vision 6 32-6830
Hitachi	L32HP01E
Humax	LP32-TDR1
LG	19LE3300
LG	19LS3500-ZA
LG	19LS350S-ZA
LG	19LS4DZS
LG	22LE3300
LG	22LE5500
LG	22LS3500-ZA
LG	22LS350S-ZA
LG	22LS3510-ZB
LG	22LS3590-ZC
LG	26CS460S-ZA
LG	26CS460-ZA
LG	26LE3300
LG	26LE5500
LG	26LS3500-ZA
LG	26LS350S-ZA
LG	26LS3510-ZB
LG	26LS3590-ZC
LG	26LS359S-ZC
LG	32CS460S-ZA
LG	32CS460-ZA
LG	32CS560-ZD
LG	32LD350
LG	32LD420
LG	32LD450
LG	32LD540
LG	32LD550
LG	32LD551
LG	32LD570
LG	32LD650
LG	32LD651
LG	32LD750
LG	32LD751
LG	32LE3300
LG	32LE5300
LG	32LE5310
LG	32LE5400
LG	32LE5500
LG	32LE5700
LG	32LE7500
LG	32LF7300
LG	32LM3400-ZA
LG	32LM340S-ZA

LG	32LM580S-ZA
LG	32LM611S-ZE
LG	32LM620S-ZE
LG	32LM621S-ZD
LG	32LM640S-ZA
LG	32LM660S-ZA
LG	32LM669S-ZC
LG	32LS3400-ZC
LG	32LS340S-ZC
LG	32LS3450-ZA
LG	32LS3500-ZA
LG	32LS350S-ZA
LG	32LS3510-ZB
LG	32LS3590-ZC
LG	32LS359S-ZC
LG	32LS5600-ZC
LG	32LS560S-ZC
LG	32LS5610-ZA
LG	32LS5620-ZD
LG	32LS570S-ZB
LG	37LD420
LG	37LD450
LG	37LE5300
LG	37LE5310
LG	37LE5400
LG	37LE5500
LG	37LE7500
LG	37LM3400-ZA
LG	37LM340S-ZA
LG	37LM580S-ZB
LG	37LM611S-ZE
LG	37LM620S-ZE
LG	37LM621S-ZD
LG	37LS3400-ZC
LG	37LS340S-ZC
LG	37LS5600-ZC
LG	37LS560S-ZC
LG	37LS570S-ZB
LG	42CS460S-ZA
LG	42CS460-ZA
LG	42CS560-ZD
LG	42LD420
LG	42LD450
LG	42LD540
LG	42LD550
LG	42LD551
LG	42LD570
LG	42LD650
LG	42LD651
LG	42LD750

LG	42LD751
LG	42LE5300
LG	42LE5310
LG	42LE5400
LG	42LE5500
LG	42LE5700
LG	42LE7500
LG	42LE8500
LG	42LF5700
LG	42LH5700
LG	42LM3400-ZA
LG	42LM340S-ZA
LG	42LM580S-ZA
LG	42LM615S-ZE
LG	42LM620S-ZE
LG	42LM621S-ZD
LG	42LM640S-ZA
LG	42LM660S-ZA
LG	42LM669S-ZC
LG	42LM670S-ZA
LG	42LM671S-ZB
LG	42LM760S-ZB
LG	42LM761S-ZA
LG	42LM765S-ZD
LG	42LM860V-ZB
LG	42LS3400-ZC
LG	42LS340S-ZC
LG	42LS3450-ZA
LG	42LS5600-ZC
LG	42LS560S-ZC
LG	42LS5610-ZA
LG	42LS5620-ZD
LG	42LS570S-ZB
LG	42PC55/42"
LG	46LD550
LG	46LD551
LG	47CM960S-ZC
LG	47CS560-ZD
LG	47LD420
LG	47LD450
LG	47LD650
LG	47LD651
LG	47LD750
LG	47LD751
LG	47LE5300
LG	47LE5310
LG	47LE5400
LG	47LE5500
LG	47LE7500
LG	47LE8500

LG	47LM580S-ZA
LG	47LM615S-ZE
LG	47LM620S-ZE
LG	47LM621S-ZD
LG	47LM640S-ZA
LG	47LM660S-ZA
LG	47LM669S-ZC
LG	47LM670S-ZA
LG	47LM671S-ZB
LG	47LM760S-ZB
LG	47LM761S-ZA
LG	47LM765S-ZD
LG	47LM860V-ZB
LG	47LM940V-ZA
LG	47LM960V-ZB
LG	47LS5600-ZC
LG	47LS560S-ZC
LG	47LS5610-ZA
LG	47LS5620-ZD
LG	50LS4000-ZA
LG	50PK760
LG	50PK950
LG	52LD550
LG	52LD551
LG	55LD650
LG	55LD651
LG	55LE5300
LG	55LE5310
LG	55LE5500
LG	55LE7500
LG	55LE8500
LG	55LM615S-ZE
LG	55LM620S-ZE
LG	55LM621S-ZD
LG	55LM640S-ZA
LG	55LM660S-ZA
LG	55LM670S-ZA
LG	55LM671S-ZB
LG	55LM760S-ZB
LG	55LM761S-ZA
LG	55LM765S-ZD
LG	55LM860V-ZB
LG	55LM940V-ZA
LG	55LM960V-ZB
LG	60LD550
LG	60LD551
LG	60LM645S-ZA
LG	60PK950
LG	65LM620S-ZB
LG	65LM621S-ZA

LG	72LM950V-ZA
LG	84LM960V-ZA
LG	DBRH198
LG	DM2352D-PZ
LG	DM2382D-PZ
LG	DM2752D-PZ
LG	LT/75/42"
LG	LT75/32"
LG	LT75/37"
LG	M2252D-PZ
LG	M2255D-PZ
LG	M2352D-PZ
LG	M2382D-PZ
LG	M2452D-PZ
LG	M2482D-PZ
LG	M2752D-PZ
LG	M2755D-PZ
LOEWE	ART 32 LED
LOEWE	ART 32 LED DR+
LOEWE	ART 32 LED SL DR
LOEWE	ART 32 SL
LOEWE	ART 32 SL FULL-HD+ 100 CI+
LOEWE	ART 32 SL FULL-HD+ 100 CI+/DR+
LOEWE	ART 37 DR+
LOEWE	ART 37 LED
LOEWE	ART 37 SL
LOEWE	ART 37 SL FULL-HD+ 100 CI+
LOEWE	ART 37 SL FULL-HD+ 100 CI+/DR+
LOEWE	ART 40 LED 200
LOEWE	ART 40 LED 200 DR+
LOEWE	ART 42 SL
LOEWE	ART 42 SL DR+
LOEWE	ART 42 SL FULL-HD+ 100 CI+
LOEWE	ART 42 SL FULL-HD+ 100 CI+/DR+
LOEWE	ART 46 LED 200
LOEWE	ART 46 LED 200 DR+
LOEWE	ART 47 SL
LOEWE	ART 47 SL DR+
LOEWE	ART 47 SL FULL-HD+ 100 CI+
LOEWE	ART 47 SL FULL-HD+ 100 CI+/DR+
LOEWE	CONNECT 32 FULL-HD+ 100 CI+
LOEWE	CONNECT 32 MEDIA FULL-HD+ 100 CI+
LOEWE	CONNECT 32 MEDIA FULL-HD+ 100 CI+/DR+
LOEWE	CONNECT 37 FULL-HD+ 100 CI+
LOEWE	CONNECT 37 MEDIA FULL-HD+ 100 CI+
LOEWE	CONNECT 37 MEDIA FULL-HD+ 100 CI+/DR+
LOEWE	CONNECT 42 FULL-HD+ 100 CI+
LOEWE	CONNECT 42 MEDIA FULL-HD+ 100 CI+
LOEWE	CONNECT 42 MEDIA FULL-HD+ 100 CI+/DR+
LOEWE	CONNECTED 26 LED

LOEWE	CONNECTED 32
LOEWE	CONNECTED 32 LED
LOEWE	CONNECTED 32 LED DR+
LOEWE	CONNECTED 32 MEDIA
LOEWE	CONNECTED 32 MEDIA DR+
LOEWE	CONNECTED 37
LOEWE	CONNECTED 37 MEDIA
LOEWE	CONNECTED 37 MEDIA DR+
LOEWE	CONNECTED 40 LED 200
LOEWE	CONNECTED 40 LED 200 DR+
LOEWE	CONNECTED 42 MEDIA
LOEWE	CONNECTED 42 MEDIA DR+
LOEWE	INDIVIDUAL 32 COMPOSE SOUND LED DR+
LOEWE	INDIVIDUAL 32 SELECTION
LOEWE	INDIVIDUAL 32 SELECTION DR+
LOEWE	INDIVIDUAL 32 SELECTION FULL-HD+ 100 CI+
LOEWE	INDIVIDUAL 32 SELECTION FULL-HD+ 100 CI+/DR+
LOEWE	INDIVIDUAL 32 SELECTION SOUND LED
LOEWE	INDIVIDUAL 40 COMPOSE DR+
LOEWE	INDIVIDUAL 40 COMPOSE FULL-HD+ 100 CI+/DR+
LOEWE	INDIVIDUAL 40 COMPOSE LED 400 DR+
LOEWE	INDIVIDUAL 40 SELECTION
LOEWE	INDIVIDUAL 40 SELECTION DR+
LOEWE	INDIVIDUAL 40 SELECTION FULL-HD+ 100 CI+
LOEWE	INDIVIDUAL 40 SELECTION FULL-HD+ 100 CI+/DR+
LOEWE	INDIVIDUAL 40 SELECTION LED 200
LOEWE	INDIVIDUAL 40 SELECTION LED 200 DR+
LOEWE	INDIVIDUAL 46 COMPOSE DR+
LOEWE	INDIVIDUAL 46 COMPOSE FULL-HD+ 100 CI+/DR+
LOEWE	INDIVIDUAL 46 COMPOSE LED 400 DR+
LOEWE	INDIVIDUAL 46 ELECTION LED 200 DR+
LOEWE	INDIVIDUAL 46 SELECTION DR+
LOEWE	INDIVIDUAL 46 SELECTION FULL-HD+ 100 CI+
LOEWE	INDIVIDUAL 46 SELECTION LED 200
LOEWE	INDIVIDUAL 52 COMPOSE DR+
LOEWE	INDIVIDUAL 55 COMPOSE LED 400 DR+
LOEWE	MODUS 32
LOEWE	MODUS 37
LOEWE	REFERENCE 52
LOEWE	SL121
LOEWE	XELOS 32 LED
LOEWE	XELOS 32 SL
LOEWE	XELOS 32 SL
LOEWE	XELOS 32 SL DR+
LOEWE	XELOS 37 SL
LOEWE	XELOS 37 SL DR+
LOEWE	XELOS 40 LED
LOEWE	XELOS 42 SL
LOEWE	XELOS 42 SL DR+
LOEWE	XELOS A 32 DR+

LOEWE	XELOS A 32 FULL-HD+ 100 CI+
LOEWE	XELOS A 32 FULL-HD+ 100 CI+/DR+
METZ	AXIO 26 LED CT Z
METZ	AXIO 32 FHD CT
METZ	AXIO 32 FHDTV 100 CT Z
METZ	AXIO 37 FHD CT
METZ	AXIO 37 FHDTV 100 CT Z
METZ	AXIO 42 FHDTV 100 CT Z
METZ	Axio pro FHDTV 100 CT Z
METZ	Axio pro FHDTV 100 CT Z
METZ	CALEO 37 LED 100 TWIN R
METZ	CALEO 47 LED 100 TWIN R
METZ	LINEA 26 FHDTV CTS2
METZ	LINEA 26 LED CT
METZ	LINEA 26 LED S2
METZ	LINEA 32 FHD CT
METZ	LINEA 32 FHD S2
METZ	LINEA 32 FHDTV 100 CT
METZ	LINEA 32 FHDTV 100 S2
METZ	LINEA 32 FHDTV CT
METZ	LINEA 32 FHDTV S2
METZ	LINEA 37 FHD CT
METZ	LINEA 37 FHD S2
METZ	LINEA 37 FHDTV 100 CT
METZ	LINEA 37 FHDTV 100 S2
METZ	LINEA 37 FHDTV CT
METZ	LINEA 37 FHDTV S2
METZ	LINUS 32 FHDTV 100 TWIN Z
METZ	LINUS 32 LED 100 TWIN Z
METZ	LINUS 37 FHDTV 100 TWIN Z
METZ	LINUS 37 LED 100 TWIN Z
METZ	LINUS 42 LED 100 TWIN Z
METZ	Linus FHDTV 100 twin Z
METZ	METZ-Axio pro FHDTV 100 CT Z
METZ	METZ-Sirius FHDTV 100 twin R
METZ	METZ-Talio FHDTV 100 CTS2 Z
METZ	MONDIAL 32 FHDTV 100 TWIN Z
METZ	MONDIAL 37 FHDTV 100 TWIN Z
METZ	Mondial FHDTV 100 twin R
METZ	PRIMUS 42 LED 200 TWIN Z
METZ	PRIMUS 55 LED 200 TWIN Z
METZ	Primus FHDTV 100 twin R
METZ	Primus FHDTV 200 twin R
METZ	Primus LED 200 twin R
METZ	PUROS 32 FHDTV 100 CT
METZ	PUROS 32 FHDTV 100 CTS2 Z
METZ	PUROS 32 FHDTV 100 TWIN R
METZ	PUROS 37 FHDTV 100 CT
METZ	PUROS 37 FHDTV 100 CTS2 Z
METZ	PUROS 37 FHDTV 100 TWIN R

METZ	Puros FHDTV 100 CTS2 Z
METZ	Puros FHDTV 100 CTS2 Z
METZ	SIRIUS 37 FHDTV 100 TWIN R
METZ	SIRIUS 37 LED 100 TWIN R
METZ	SIRIUS 42 FHDTV 100 TWIN R
METZ	SIRIUS 42 LED 200 TWIN R
METZ	Sirius FHDTV 100 twin R
METZ	Talio FHDTV 100 CTS2 Z
METZ	Talio FHDTV CTS2
METZ	TALLO 26 FHDTV CTS2
METZ	TALLO 32 FHDTV 100 CTS2 Z
METZ	TALLO 37 FHDTV 100 CTS2 Z
Mstar	A7MFM27D
Panasonic	LXD70F
Panasonic	LZD70
Panasonic	LZD80F
Panasonic	PX70E
Panasonic	PX80E
Panasonic	PZ70E
Panasonic	TH-37PX70E
Panasonic	TH-37PX7E
Panasonic	TH-37PX80E
Panasonic	TH-37PX81FV
Panasonic	TH42PX70
Panasonic	TH-42PX700E
Panasonic	TH-42PX70E
Panasonic	TH-42PX74E
Panasonic	TH-42PX7E
Panasonic	TH-42PX80E
Panasonic	TH-42PX81FV
Panasonic	TH-42PZ700E
Panasonic	TH-42PZ80E
Panasonic	TH-42PZ81FV
Panasonic	TH-42PZ85E
Panasonic	TH-42PZ86FV
Panasonic	TH-46PZ80E
Panasonic	TH-46PZ81FV
Panasonic	TH-46PZ86FV
Panasonic	TH-50PX700E
Panasonic	TH-50PX70E
Panasonic	TH-50PX7E
Panasonic	TH-50PZ700E
Panasonic	TH-50PZ800E
Panasonic	TH-50PZ80E
Panasonic	TH-D42PN83EA
Panasonic	TH-D42PS81E
Panasonic	TX-26LED7F
Panasonic	TX-26LMD70F
Panasonic	TX-26LXD70E
Panasonic	TX-32LED7F



Panasonic	TX-32LED8F
Panasonic	TX-32LMD70F
Panasonic	TX-32LXD700F
Panasonic	TX-32LXD70F
Panasonic	TX-32LXD86FV
Panasonic	TX-37LXD85F
Panasonic	TX-37LXD86FV
Panasonic	TX-37LZD800F
Panasonic	TX-37LZD80F
Panasonic	TX-37LZD85F
Panasonic	TX-42GA11
Panasonic	TX-46GA11
Panasonic	TX-L19C20E
Panasonic	TX-L19C20EW
Panasonic	TX-L19D28
Panasonic	TX-L19D28EP
Panasonic	TX-L19D28EP(LED)
Panasonic	TX-L19D28EW
Panasonic	TX-L19D28EW(LED)
Panasonic	TX-L19D35ES
Panasonic	TX-L19D35EW
Panasonic	TX-L19E3E
Panasonic	TX-L22D28
Panasonic	TX-L22D28EP
Panasonic	TX-L22D28EP(LED)
Panasonic	TX-L22D28EW
Panasonic	TX-L22D28EW(LED)
Panasonic	TX-L22X20
Panasonic	TX-L22X20E
Panasonic	TX-L24C3E
Panasonic	TX-L24C3ES
Panasonic	TX-L24D35ES
Panasonic	TX-L24D35EW
Panasonic	TX-L24E3E
Panasonic	TX-L26C20
Panasonic	TX-L26C20E
Panasonic	TX-L26C20ES
Panasonic	TX-L26X10Y
Panasonic	TX-L26X20
Panasonic	TX-L26X20E
Panasonic	TX-L32C2
Panasonic	TX-L32C20
Panasonic	TX-L32C20E
Panasonic	TX-L32C20ES
Panasonic	TX-L32C2E
Panasonic	TX-L32C3E
Panasonic	TX-L32C3ES
Panasonic	TX-L32CX3E
Panasonic	TX-L32D25
Panasonic	TX-L32D25E

Panasonic	TX-L32D25E(LED)
Panasonic	TX-L32D28
Panasonic	TX-L32D28EP
Panasonic	TX-L32D28EP(LED)
Panasonic	TX-L32D28ES
Panasonic	TX-L32D28ES(LED)
Panasonic	TX-L32D28EW
Panasonic	TX-L32D28EW(LED)
Panasonic	TX-L32DT30E
Panasonic	TX-L32DT30Y
Panasonic	TX-L32DT35E
Panasonic	TX-L32E30Y
Panasonic	TX-L32E3E
Panasonic	TX-L32E5E
Panasonic	TX-L32EF32
Panasonic	TX-L32EN33
Panasonic	TX-L32ES31
Panasonic	TX-L32ETF52
Panasonic	TX-L32ETN53
Panasonic	TX-L32ETS51
Panasonic	TX-L32ETW5
Panasonic	TX-L32ETW5W
Panasonic	TX-L32ETX54
Panasonic	TX-L32EW30
Panasonic	TX-L32EW30S
Panasonic	TX-L32EW5
Panasonic	TX-L32EW5S
Panasonic	TX-L32EX34
Panasonic	TX-L32G10E
Panasonic	TX-L32G20E
Panasonic	TX-L32G20ES
Panasonic	TX-L32GA11
Panasonic	TX-L32GF22
Panasonic	TX-L32GN23
Panasonic	TX-L32GS21
Panasonic	TX-L32GT24
Panasonic	TX-L32GW20
Panasonic	TX-L32S10E
Panasonic	TX-L32S20
Panasonic	TX-L32S20E
Panasonic	TX-L32S20ES
Panasonic	TX-L32U10E
Panasonic	TX-L32U2
Panasonic	TX-L32U2E
Panasonic	TX-L32V10E
Panasonic	TX-L32X10Y
Panasonic	TX-L32X20E
Panasonic	TX-L32X25
Panasonic	TX-L32X25E
Panasonic	TX-L32X25ES

Panasonic	TX-L32X5E
Panasonic	TX-L37D25
Panasonic	TX-L37D25E
Panasonic	TX-L37D25E(LED)
Panasonic	TX-L37D28
Panasonic	TX-L37D28ES
Panasonic	TX-L37D28ES(LED)
Panasonic	TX-L37D28EW
Panasonic	TX-L37D28EW(LED)
Panasonic	TX-L37DT30E
Panasonic	TX-L37DT30Y
Panasonic	TX-L37DT35E
Panasonic	TX-L37E30Y
Panasonic	TX-L37E3E
Panasonic	TX-L37E5E
Panasonic	TX-L37EF32
Panasonic	TX-L37EN33
Panasonic	TX-L37ES31
Panasonic	TX-L37ETF52
Panasonic	TX-L37ETN53
Panasonic	TX-L37ETS51
Panasonic	TX-L37ETW5
Panasonic	TX-L37ETW5W
Panasonic	TX-L37ETX54
Panasonic	TX-L37EW30
Panasonic	TX-L37EW30S
Panasonic	TX-L37EW5
Panasonic	TX-L37EW5S
Panasonic	TX-L37EX34
Panasonic	TX-L37G10E
Panasonic	TX-L37G15E
Panasonic	TX-L37G20E
Panasonic	TX-L37G20ES
Panasonic	TX-L37GF22
Panasonic	TX-L37GN23
Panasonic	TX-L37GS21
Panasonic	TX-L37GT24
Panasonic	TX-L37GW20
Panasonic	TX-L37S10E
Panasonic	TX-L37S20
Panasonic	TX-L37S20E
Panasonic	TX-L37S20ES
Panasonic	TX-L37U10E
Panasonic	TX-L37U2
Panasonic	TX-L37U2E
Panasonic	TX-L37V10E
Panasonic	TX-L37V20
Panasonic	TX-L37V20E
Panasonic	TX-L37V20E(LED)
Panasonic	TX-L42D25

Panasonic	TX-L42D25E
Panasonic	TX-L42D25E(LED)
Panasonic	TX-L42DT50E
Panasonic	TX-L42E30Y
Panasonic	TX-L42E3E
Panasonic	TX-L42E5E
Panasonic	TX-L42EF32
Panasonic	TX-L42EN33
Panasonic	TX-L42ES31
Panasonic	TX-L42ETF52
Panasonic	TX-L42ETN53
Panasonic	TX-L42ETS51
Panasonic	TX-L42ETW5
Panasonic	TX-L42ETW50
Panasonic	TX-L42ETW5W
Panasonic	TX-L42ETX54
Panasonic	TX-L42EW30
Panasonic	TX-L42EW5
Panasonic	TX-L42EW5S
Panasonic	TX-L42EX34
Panasonic	TX-L42G20E
Panasonic	TX-L42G20ES
Panasonic	TX-L42GW20
Panasonic	TX-L42S10E
Panasonic	TX-L42S20
Panasonic	TX-L42S20E
Panasonic	TX-L42U10E
Panasonic	TX-L42U2
Panasonic	TX-L42U2E
Panasonic	TX-L42V20
Panasonic	TX-L42V20E
Panasonic	TX-L42V20E(LED)
Panasonic	TX-L42WT50E
Panasonic	TX-L47DT50E
Panasonic	TX-L47E5E
Panasonic	TX-L47ETF52
Panasonic	TX-L47ETN53
Panasonic	TX-L47ETS51
Panasonic	TX-L47ETW5
Panasonic	TX-L47ETW50
Panasonic	TX-L47ETX54
Panasonic	TX-L47EW5
Panasonic	TX-L47WT50E
Panasonic	TX-L55DT50E
Panasonic	TX-L55ETW5
Panasonic	TX-L55WT50E
Panasonic	TX-P37C10Y
Panasonic	TX-P37C2
Panasonic	TX-P37C2E
Panasonic	TX-P37X10Y

Panasonic	TX-P37X20E
Panasonic	TX-P37X25
Panasonic	TX-P42C10Y
Panasonic	TX-P42C2
Panasonic	TX-P42C2E
Panasonic	TX-P42C3E
Panasonic	TX-P42CX3E
Panasonic	TX-P42G10E
Panasonic	TX-P42G15E
Panasonic	TX-P42G20E
Panasonic	TX-P42G20E(NeoPDP)
Panasonic	TX-P42G20ES
Panasonic	TX-P42G20ES(NeoPDP)
Panasonic	TX-P42G30Y
Panasonic	TX-P42GF22
Panasonic	TX-P42GN23
Panasonic	TX-P42GS21
Panasonic	TX-P42GT20
Panasonic	TX-P42GT20E
Panasonic	TX-P42GT24
Panasonic	TX-P42GT30E
Panasonic	TX-P42GT30Y
Panasonic	TX-P42GT50E
Panasonic	TX-P42GTF32
Panasonic	TX-P42GTN33
Panasonic	TX-P42GTS31
Panasonic	TX-P42GTX34
Panasonic	TX-P42GW20
Panasonic	TX-P42GW30
Panasonic	TX-P42GW30S
Panasonic	TX-P42S10E
Panasonic	TX-P42S20
Panasonic	TX-P42S20E
Panasonic	TX-P42S20ES
Panasonic	TX-P42S30E
Panasonic	TX-P42S30Y
Panasonic	TX-P42ST32Y
Panasonic	TX-P42ST33E
Panasonic	TX-P42ST33ES
Panasonic	TX-P42STW50
Panasonic	TX-P42U10E
Panasonic	TX-P42U20
Panasonic	TX-P42U20E
Panasonic	TX-P42U30E
Panasonic	TX-P42UT50E
Panasonic	TX-P42UX30E
Panasonic	TX-P42V10E
Panasonic	TX-P42V20
Panasonic	TX-P42V20E
Panasonic	TX-P42V20E(NeoPDP)

Panasonic	TX-P42VT20
Panasonic	TX-P42VT20E
Panasonic	TX-P42VT30E
Panasonic	TX-P42VT30Y
Panasonic	TX-P42X10Y
Panasonic	TX-P42X20E
Panasonic	TX-P42X25
Panasonic	TX-P42X50E
Panasonic	TX-P46G10E
Panasonic	TX-P46G15E
Panasonic	TX-P46G20E
Panasonic	TX-P46G20E(NeoPDP)
Panasonic	TX-P46G20ES
Panasonic	TX-P46G20ES(NeoPDP)
Panasonic	TX-P46G30Y
Panasonic	TX-P46GQ21
Panasonic	TX-P46GT30E
Panasonic	TX-P46GT30Y
Panasonic	TX-P46GTF32
Panasonic	TX-P46GTN33
Panasonic	TX-P46GTS31
Panasonic	TX-P46GTX34
Panasonic	TX-P46GW20
Panasonic	TX-P46GW30
Panasonic	TX-P46S10E
Panasonic	TX-P46S20
Panasonic	TX-P46S20E
Panasonic	TX-P46ST32Y
Panasonic	TX-P46ST33E
Panasonic	TX-P46U20
Panasonic	TX-P46U20E
Panasonic	TX-P46VT20
Panasonic	TX-P46VT20E
Panasonic	TX-P46Z1E
Panasonic	TX-P50C10Y
Panasonic	TX-P50C2
Panasonic	TX-P50C2E
Panasonic	TX-P50C3E
Panasonic	TX-P50G10E
Panasonic	TX-P50G20E
Panasonic	TX-P50G20E(NeoPDP)
Panasonic	TX-P50G20ES
Panasonic	TX-P50G20ES(NeoPDP)
Panasonic	TX-P50G30Y
Panasonic	TX-P50GT30E
Panasonic	TX-P50GT30Y
Panasonic	TX-P50GT50E
Panasonic	TX-P50GW20
Panasonic	TX-P50GW30
Panasonic	TX-P50S10E

Panasonic	TX-P50S20
Panasonic	TX-P50S20E
Panasonic	TX-P50ST32Y
Panasonic	TX-P50ST33E
Panasonic	TX-P50STW50
Panasonic	TX-P50U10E
Panasonic	TX-P50U20
Panasonic	TX-P50U20E
Panasonic	TX-P50U30E
Panasonic	TX-P50UT50E
Panasonic	TX-P50V10E
Panasonic	TX-P50V20
Panasonic	TX-P50V20E
Panasonic	TX-P50V20E(NeoPDP)
Panasonic	TX-P50VT20
Panasonic	TX-P50VT20E
Panasonic	TX-P50VT20E(3D)
Panasonic	TX-P50VT30E
Panasonic	TX-P50VT30Y
Panasonic	TX-P50VT50E
Panasonic	TX-P50X10Y
Panasonic	TX-P50X20E
Panasonic	TX-P50X25
Panasonic	TX-P50X50E
Panasonic	TX-P54Z1E
Panasonic	TX-P55STW50
Panasonic	TX-P55VT30E
Panasonic	TX-P55VT30Y
Panasonic	TX-P55VT50E
Panasonic	TX-P65STW50
Panasonic	TX-P65VT20
Panasonic	TX-P65VT20E
Panasonic	TX-P65VT20E(3D)
Panasonic	TX-P65VT30E
Panasonic	TX-P65VT30Y
Panasonic	TX-P65VT50E
Philips	19PFL5404H/12
Philips	22PFL5604H/12
Philips	22PFL5614H/12
Philips	26PF9631D
Philips	26PFL4007H/12
Philips	26PFL4007K/12
Philips	26PFL4007T/12
Philips	26PFL4007T/60
Philips	26PFL5604H/12
Philips	32PDL7906H/12
Philips	32PDL7906K/02
Philips	32PDL7906M/08
Philips	32PDL7906T/12
Philips	32PF9631D

Philips	32PF9641D
Philips	32PF9731D
Philips	32PFL3403D/12
Philips	32PFL3705H/12
Philips	32PFL3805H/12
Philips	32PFL4007H/12
Philips	32PFL4007H/60
Philips	32PFL4007K/12
Philips	32PFL4007M/08
Philips	32PFL4007T/12
Philips	32PFL4007T/60
Philips	32PFL4027H/12
Philips	32PFL4027K/12
Philips	32PFL4027M/08
Philips	32PFL4027T/12
Philips	32PFL4027T/60
Philips	32PFL4037H/12
Philips	32PFL4037K/12
Philips	32PFL4037M/08
Philips	32PFL4037T/12
Philips	32PFL4037T/60
Philips	32PFL4047T/12
Philips	32PFL5403D/10
Philips	32PFL5403D/12
Philips	32PFL5403H/10
Philips	32PFL5404H/12
Philips	32PFL5405H/12
Philips	32PFL5604H/12
Philips	32PFL5605H/12
Philips	32PFL5625H/12
Philips	32PFL6605H/12
Philips	32PFL6606H/12
Philips	32PFL6606K/02
Philips	32PFL6606M/08
Philips	32PFL6606T/12
Philips	32PFL6626H/12
Philips	32PFL6626K/02
Philips	32PFL6626T/12
Philips	32PFL6636H/12
Philips	32PFL6636K/02
Philips	32PFL6636T/12
Philips	32PFL7403D/10
Philips	32PFL7403D/12
Philips	32PFL7403H/10
Philips	32PFL7404H/12
Philips	32PFL7406H/12
Philips	32PFL7406K/02
Philips	32PFL7406M/08
Philips	32PFL7406T/12
Philips	32PFL7423D/10



Philips	32PFL7423H/10
Philips	32PFL7433D/10
Philips	32PFL7476H/12
Philips	32PFL7476K/02
Philips	32PFL7486H/12
Philips	32PFL7486K/02
Philips	32PFL7486M/08
Philips	32PFL7486T/12
Philips	32PFL7496H/12
Philips	32PFL7496K/02
Philips	32PFL7603D/10
Philips	32PFL7603D/12
Philips	32PFL7603H/10
Philips	32PFL7605C/12
Philips	32PFL7605H/12
Philips	32PFL7606H/12
Philips	32PFL7606K/02
Philips	32PFL7606M/08
Philips	32PFL7606T/12
Philips	32PFL7613D/10
Philips	32PFL7623D/10
Philips	32PFL7665H/12
Philips	32PFL7674H/12
Philips	32PFL7675H/12
Philips	32PFL7675K/02
Philips	32PFL7684H/12
Philips	32PFL7685H/12
Philips	32PFL7685K/02
Philips	32PFL7694H/12
Philips	32PFL7695H/12
Philips	32PFL7695K/02
Philips	32PFL7803D/10
Philips	32PFL7803D/12
Philips	32PFL7803H/10
Philips	32PFL7862D
Philips	32PFL7864H/12
Philips	32PFL8404H/12
Philips	32PFL8605H/12
Philips	32PFL8605K/02
Philips	32PFL9603D/10
Philips	32PFL9603H/10
Philips	32PFL9604H/12
Philips	32PFL9606H/12
Philips	32PFL9606K/02
Philips	32PFL9606M/08
Philips	32PFL9606T/12
Philips	32PFL9613D/10
Philips	32PFL9613H/10
Philips	32PFL9632D
Philips	32PFL9705K/02

Philips	37PF7641D
Philips	37PF9631D
Philips	37PF9641D
Philips	37PFL3403D/12
Philips	37PFL4007H/12
Philips	37PFL4007K/12
Philips	37PFL4007M/08
Philips	37PFL4007T/12
Philips	37PFL4007T/60
Philips	37PFL5405H/12
Philips	37PFL5603D/10
Philips	37PFL5603H/10
Philips	37PFL5604H/12
Philips	37PFL6606K/02
Philips	37PFL6606M/08
Philips	37PFL6606T/12
Philips	37PFL7403D/10
Philips	37PFL7403H/10
Philips	37PFL7603D/10
Philips	37PFL7603H/10
Philips	37PFL7605H/12
Philips	37PFL7606H/12
Philips	37PFL7606K/02
Philips	37PFL7606M/08
Philips	37PFL7606T/12
Philips	37PFL7666H/12
Philips	37PFL7666K/02
Philips	37PFL7675H/12
Philips	37PFL7675K/02
Philips	37PFL7676H/12
Philips	37PFL7676K/02
Philips	37PFL8404H/12
Philips	37PFL8605H/12
Philips	37PFL8605K/02
Philips	37PFL8684H/12
Philips	37PFL8694H/12
Philips	37PFL9603D/10
Philips	37PFL9603H/10
Philips	37PFL9604H/12
Philips	37PFL9606H/12
Philips	37PFL9606K/02
Philips	37PFL9606M/08
Philips	37PFL9606T/12
Philips	37PFL9632D
Philips	37PFL9732D
Philips	37PFL9903H/10
Philips	40PFL5605H/12
Philips	40PFL5605K/02
Philips	40PFL5625H/12
Philips	40PFL5705H/12

Philips	40PFL5805H/12
Philips	40PFL6605H/12
Philips	40PFL6606K/02
Philips	40PFL6606M/08
Philips	40PFL6606T/12
Philips	40PFL6626T/12
Philips	40PFL6636T/12
Philips	40PFL7605H/12
Philips	40PFL7664H/12
Philips	40PFL8605H/12
Philips	40PFL8605K/02
Philips	40PFL8606H/12
Philips	40PFL8606K/02
Philips	40PFL8606M/08
Philips	40PFL8606T/12
Philips	40PFL8664H/12
Philips	40PFL9606H/12
Philips	40PFL9606K/02
Philips	40PFL9606M/08
Philips	40PFL9606T/12
Philips	40PFL9704H/12
Philips	40PFL9705K/02
Philips	40PFL9715K/02
Philips	40PFL9904H/12
Philips	42PDL7906H/12
Philips	42PDL7906K/02
Philips	42PDL7906M/08
Philips	42PDL7906T/12
Philips	42PES0001D/10
Philips	42PES0001H/10
Philips	42PF9631D
Philips	42PF9641D
Philips	42PF9731D
Philips	42PF9831D
Philips	42PFL3403D/12
Philips	42PFL3604/12
Philips	42PFL3605H/12
Philips	42PFL4007H/12
Philips	42PFL4007H/60
Philips	42PFL4007K/12
Philips	42PFL4007M/08
Philips	42PFL4007T/12
Philips	42PFL4007T/60
Philips	42PFL4047T/12
Philips	42PFL4307H/12
Philips	42PFL5405H/12
Philips	42PFL5603D/10
Philips	42PFL5603D/12
Philips	42PFL5603H/10
Philips	42PFL5604H/12

Philips	42PFL7403D/10
Philips	42PFL7403H/10
Philips	42PFL7404H/12
Philips	42PFL7406H/12
Philips	42PFL7406K/02
Philips	42PFL7406M/08
Philips	42PFL7406T/12
Philips	42PFL7423D/12
Philips	42PFL7423H/12
Philips	42PFL7433D/12
Philips	42PFL7456H/12
Philips	42PFL7456K/02
Philips	42PFL7456M/08
Philips	42PFL7456T/12
Philips	42PFL7486H/12
Philips	42PFL7486K/02
Philips	42PFL7486M/08
Philips	42PFL7486T/12
Philips	42PFL7603D/10
Philips	42PFL7603D/12
Philips	42PFL7603H/10
Philips	42PFL7605C/12
Philips	42PFL7606H/12
Philips	42PFL7606K/02
Philips	42PFL7606M/08
Philips	42PFL7606T/12
Philips	42PFL7613D/10
Philips	42PFL7623D/10
Philips	42PFL7633D/10
Philips	42PFL7655H/12
Philips	42PFL7655K/02
Philips	42PFL7656H/12
Philips	42PFL7656K/02
Philips	42PFL7665H/12
Philips	42PFL7665H/12
Philips	42PFL7666H/12
Philips	42PFL7666K/02
Philips	42PFL7674H/12
Philips	42PFL7675H/12
Philips	42PFL7675K/02
Philips	42PFL7676H/12
Philips	42PFL7676K/02
Philips	42PFL7676T/12
Philips	42PFL7685H/12
Philips	42PFL7685K/02
Philips	42PFL7695H/12
Philips	42PFL7695K/02
Philips	42PFL7696H/12
Philips	42PFL7696K/02
Philips	42PFL7696M/08

Philips	42PFL7696T/12
Philips	42PFL7862D
Philips	42PFL7864H/12
Philips	42PFL8404H/12
Philips	42PFL8654H/12
Philips	42PFL8684H/12
Philips	42PFL8694H/12
Philips	42PFL9603D/10
Philips	42PFL9603H/10
Philips	42PFL9632D
Philips	42PFL9664H/12
Philips	42PFL9703D/10
Philips	42PFL9703H/10
Philips	42PFL9732D
Philips	42PFL9803H/10
Philips	42PFL9900D
Philips	42PFL9903H/10
Philips	46PFL5605H/12
Philips	46PFL5805H/12
Philips	46PFL6606M/08
Philips	46PFL6606T/12
Philips	46PFL6626T/12
Philips	46PFL7605H/12
Philips	46PFL7655K/02
Philips	46PFL7665H/12
Philips	46PFL7695H/12
Philips	46PFL7695K/02
Philips	46PFL8605H/12
Philips	46PFL8605K/02
Philips	46PFL8606H/12
Philips	46PFL8606K/02
Philips	46PFL8606M/08
Philips	46PFL8606T/12
Philips	46PFL8685H/12
Philips	46PFL8685K/02
Philips	46PFL8686H/12
Philips	46PFL8686K/02
Philips	46PFL8686M/08
Philips	46PFL9606H/12
Philips	46PFL9606K/02
Philips	46PFL9606T/12
Philips	46PFL9704H/12
Philips	46PFL9705K/02
Philips	46PFL9706H/12
Philips	46PFL9706K/02
Philips	46PFL9706M/08
Philips	46PFL9706T/12
Philips	46PFL9715K/02
Philips	47PFL3605H/12
Philips	47PFL4007H/12

Philips	47PFL4007H/60
Philips	47PFL4007K/12
Philips	47PFL4007M/08
Philips	47PFL4007T/12
Philips	47PFL4007T/60
Philips	47PFL4047T/12
Philips	47PFL5603D/10
Philips	47PFL5603H/10
Philips	47PFL5604H/12
Philips	47PFL7403D/10
Philips	47PFL7403H/10
Philips	47PFL7404H/12
Philips	47PFL7456H/12
Philips	47PFL7456K/02
Philips	47PFL7456M/08
Philips	47PFL7456T/12
Philips	47PFL7603D/10
Philips	47PFL7603H/10
Philips	47PFL7606H/12
Philips	47PFL7606K/02
Philips	47PFL7606M/08
Philips	47PFL7606T/12
Philips	47PFL7623D/10
Philips	47PFL7656H/12
Philips	47PFL7656K/02
Philips	47PFL7666H/12
Philips	47PFL7666K/02
Philips	47PFL7696H/12
Philips	47PFL7696K/02
Philips	47PFL7696M/08
Philips	47PFL7696T/12
Philips	47PFL7864H/12
Philips	47PFL8404H/12
Philips	47PFL9532D
Philips	47PFL9603D/10
Philips	47PFL9603H/10
Philips	47PFL9632D
Philips	47PFL9664H/12
Philips	47PFL9703D/10
Philips	47PFL9703H/10
Philips	47PFL9732D
Philips	50PF9631D
Philips	50PFL7956H/12
Philips	50PFL7956K/02
Philips	50PFL7956T/12
Philips	52PFL5604H/12
Philips	52PFL5605H/12
Philips	52PFL7203H/10
Philips	52PFL7404H/12
Philips	52PFL8605H/12

Philips	52PFL8605K/02
Philips	52PFL9606H/12
Philips	52PFL9606K/02
Philips	52PFL9606M/08
Philips	52PFL9606T/12
Philips	52PFL9632D
Philips	52PFL9703D/10
Philips	52PFL9703H/10
Philips	52PFL9704H/12
Philips	55PFL6606M/08
Philips	55PFL6606T/12
Philips	55PFL7606H/12
Philips	55PFL7606K/02
Philips	55PFL7606M/08
Philips	55PFL7606T/12
Philips	56PFL9954H/12
Philips	58PFL9956H/12
Philips	58PFL9956H/12
Philips	58PFL9956T/12
Pioneer	PDP 5080XD
SAMSUNG	LE19C450E1WXZG
SAMSUNG	LE19C451E2WXZG
SAMSUNG	LE22C450E1WXZG
SAMSUNG	LE22C451E2WXZG
SAMSUNG	LE26A456
SAMSUNG	LE26C350D1WXZG
SAMSUNG	LE26C450E1WXZG
SAMSUNG	LE32A556
SAMSUNG	LE32B550A5PXXN
SAMSUNG	LE32B550A5PXZG
SAMSUNG	LE32B551A6PXXN
SAMSUNG	LE32B551A6PXZG
SAMSUNG	LE32B553M3PXXN
SAMSUNG	LE32B553M3PXZG
SAMSUNG	LE32B554M2PXXN
SAMSUNG	LE32B554M2PXZG
SAMSUNG	LE32B579A5SXZG
SAMSUNG	LE32B650T2PXXN
SAMSUNG	LE32B650T2PXZG
SAMSUNG	LE32B651T3PXXN
SAMSUNG	LE32B651T3PXZG
SAMSUNG	LE32B652T4PXXN
SAMSUNG	LE32B652T4PXZG
SAMSUNG	LE32B653T5PXXN
SAMSUNG	LE32B653T5PXZG
SAMSUNG	LE32C450E1WXZG
SAMSUNG	LE32C530F1WXZG
SAMSUNG	LE32C550
SAMSUNG	LE32C579J1SXZG
SAMSUNG	LE32C630K1WXZG

SAMSUNG	LE32C650L1WXXN
SAMSUNG	LE32C650L1WXZG
SAMSUNG	LE32C652L2WXXN
SAMSUNG	LE32C652L2WXZG
SAMSUNG	LE32C653M2WXXN
SAMSUNG	LE32C653M2WXZG
SAMSUNG	LE32C654M1WXXN
SAMSUNG	LE32C654M1WXZG
SAMSUNG	LE32C670M1SXXN
SAMSUNG	LE32C679M1SXZG
SAMSUNG	LE32M86/32"
SAMSUNG	LE32R86/32"
SAMSUNG	LE32S86/32"
SAMSUNG	LE37A558
SAMSUNG	LE37B550A5PXXN
SAMSUNG	LE37B550A5PXZG
SAMSUNG	LE37B551A6PXXN
SAMSUNG	LE37B553M3PXXN
SAMSUNG	LE37B554M2PXXN
SAMSUNG	LE37B579A5SXZG
SAMSUNG	LE37B650T2PXXN
SAMSUNG	LE37B650T2PXZG
SAMSUNG	LE37B651T3PXXN
SAMSUNG	LE37B651T3PXZG
SAMSUNG	LE37B652T4PXXN
SAMSUNG	LE37B652T4PXZG
SAMSUNG	LE37B653T5PXXN
SAMSUNG	LE37B653T5PXZG
SAMSUNG	LE37B679T2SXZG
SAMSUNG	LE37C530F1WXZG
SAMSUNG	LE37C579J1SXZG
SAMSUNG	LE37C630K1WXZG
SAMSUNG	LE37C650L1WXXN
SAMSUNG	LE37C650L1WXZG
SAMSUNG	LE37C670M1SXXN
SAMSUNG	LE37C679M1SXZG
SAMSUNG	LE37M86/37"
SAMSUNG	LE37M87bdx/xee/37"
SAMSUNG	LE40B550A5PXXN
SAMSUNG	LE40B550A5PXZG
SAMSUNG	LE40B551A6PXXN
SAMSUNG	LE40B551A6PXZG
SAMSUNG	LE40B553M3PXXN
SAMSUNG	LE40B553M3PXZG
SAMSUNG	LE40B554M2PXXN
SAMSUNG	LE40B554M2PXZG
SAMSUNG	LE40B579A5SXZG
SAMSUNG	LE40B620R3PXXN
SAMSUNG	LE40B620R3PXZG
SAMSUNG	LE40B650T2PXXN



SAMSUNG	LE40B650T2PXZG
SAMSUNG	LE40B651T3PXXN
SAMSUNG	LE40B651T3PXZG
SAMSUNG	LE40B652T4PXXN
SAMSUNG	LE40B652T4PXZG
SAMSUNG	LE40B653T5PXXN
SAMSUNG	LE40B653T5PXZG
SAMSUNG	LE40B679T2SXZG
SAMSUNG	LE40B750U1PXXN
SAMSUNG	LE40B750U1PXZG
SAMSUNG	LE40C530F1WXZG
SAMSUNG	LE40C579J1SXZG
SAMSUNG	LE40C630K1WXZG
SAMSUNG	LE40C650L1WXXN
SAMSUNG	LE40C650L1WXZG
SAMSUNG	LE40C652L2WXXN
SAMSUNG	LE40C652L2WXZG
SAMSUNG	LE40C653M2WXXN
SAMSUNG	LE40C653M2WXZG
SAMSUNG	LE40C654M1WXXN
SAMSUNG	LE40C654M1WXZG
SAMSUNG	LE40C670M1SXXN
SAMSUNG	LE40C679M1SXZG
SAMSUNG	LE40C750R2WXXN
SAMSUNG	LE40C750R2WXZG
SAMSUNG	LE40R86x/40"
SAMSUNG	LE46B550A5PXXN
SAMSUNG	LE46B550A5PXZG
SAMSUNG	LE46B551A6PXXN
SAMSUNG	LE46B553M3PXXN
SAMSUNG	LE46B554M2PXXN
SAMSUNG	LE46B620R3PXXN
SAMSUNG	LE46B620R3PXZG
SAMSUNG	LE46B650T2PXXN
SAMSUNG	LE46B651T3PXXN
SAMSUNG	LE46B652T4PXXN
SAMSUNG	LE46B653T5PXXN
SAMSUNG	LE46B679T2SXZG
SAMSUNG	LE46B750U1PXXN
SAMSUNG	LE46B750U1PXZG
SAMSUNG	LE46C530F1WXZG
SAMSUNG	LE46C579J1SXZG
SAMSUNG	LE46C650L1WXXN
SAMSUNG	LE46C650L1WXZG
SAMSUNG	LE46C652L2WXXN
SAMSUNG	LE46C652L2WXZG
SAMSUNG	LE46C653M2WXXN
SAMSUNG	LE46C653M2WXZG
SAMSUNG	LE46C654M1WXXN
SAMSUNG	LE46C654M1WXZG

SAMSUNG	LE46C670M1SXXN
SAMSUNG	LE46C679M1SXZG
SAMSUNG	LE46C750R2WXXN
SAMSUNG	LE46C750R2WXZG
SAMSUNG	LE52B620R3PXXN
SAMSUNG	LE52B620R3PXZG
SAMSUNG	LE52B750U1PXXN
SAMSUNG	LE52B750U1PXZG
SAMSUNG	LE55B650T2PXXN
SAMSUNG	LE55B650T2PXZG
SAMSUNG	LE55B651T3PXXN
SAMSUNG	LE55B652T4PXXN
SAMSUNG	LE55B653T5PXXN
SAMSUNG	LE55B679T2SXZG
SAMSUNG	LE55C650L1WXXN
SAMSUNG	LE55C650L1WXZG
SAMSUNG	LE55C670M1SXXN
SAMSUNG	LE55C679M1SXZG
SAMSUNG	LE60C650L1WXXN
SAMSUNG	LE60C650L1WXZG
SAMSUNG	PS42A456
SAMSUNG	PS42C430A1WXXC
SAMSUNG	PS42C450B1WXXC
SAMSUNG	PS50A456
SAMSUNG	PS50A556
SAMSUNG	PS50B550T4PXXC
SAMSUNG	PS50B550T4PXXC
SAMSUNG	PS50B551T3PXXC
SAMSUNG	PS50B551T3PXXC
SAMSUNG	PS50B560T7PXXC
SAMSUNG	PS50B579T6SXZG
SAMSUNG	PS50B610S2PXXC
SAMSUNG	PS50B610S2PXXC
SAMSUNG	PS50B650S1PXXC
SAMSUNG	PS50B650S1PXXC
SAMSUNG	PS50B679S1SXZG
SAMSUNG	PS50B850Y1PXXC
SAMSUNG	PS50B859Y1PXZG
SAMSUNG	PS50C430A1WXXC
SAMSUNG	PS50C450B1WXXC
SAMSUNG	PS50C530C1WXXC
SAMSUNG	PS50C6500TWXXC
SAMSUNG	PS50C6500TWXXC
SAMSUNG	PS50C670G3SXXC
SAMSUNG	PS50C679G3SXZG
SAMSUNG	PS50C7000
SAMSUNG	PS50C7700YWXXC
SAMSUNG	PS50C7790YSXZG
SAMSUNG	PS58B680T6PXXC
SAMSUNG	PS58B680T6PXXC

SAMSUNG	PS58B850Y1PXXC
SAMSUNG	PS58B859Y1PXZG
SAMSUNG	PS58C6500TWXXC
SAMSUNG	PS58C6500TWXXC
SAMSUNG	PS63B680T6PXXC
SAMSUNG	PS63C7000YWXXC
SAMSUNG	PS63C7790YSXZG
SAMSUNG	UE19C4000PWXZG
SAMSUNG	UE22C4000PWXZG
SAMSUNG	UE22C4010PWXZG
SAMSUNG	UE26C4000PWXZG
SAMSUNG	UE32B6000VPXXN
SAMSUNG	UE32B6000VPXZG
SAMSUNG	UE32B7000WPXXN
SAMSUNG	UE32B7000WPXZG
SAMSUNG	UE32B7020WPXXN
SAMSUNG	UE32B7090WPXZG
SAMSUNG	UE32C4000PWXZG
SAMSUNG	UE32C5100QWXZG
SAMSUNG	UE32C6000RWXZG
SAMSUNG	UE32C6200RSXZG
SAMSUNG	UE32C6700USXXN
SAMSUNG	UE32C6700USXZG
SAMSUNG	UE32C6710USXXN
SAMSUNG	UE32C6710USXZG
SAMSUNG	UE32C6730USXXN
SAMSUNG	UE32C6730USXZG
SAMSUNG	UE32C6740SSXXN
SAMSUNG	UE32C6740SSXZG
SAMSUNG	UE32C6800USXXN
SAMSUNG	UE32C6800USXZG
SAMSUNG	UE32C6820USXXN
SAMSUNG	UE32C6820USXZG
SAMSUNG	UE32C8700XSXXN
SAMSUNG	UE32C8790XSXZG
SAMSUNG	UE32D4000
SAMSUNG	UE32D6500
SAMSUNG	UE37B6000VPXXN
SAMSUNG	UE37B6000VPXZG
SAMSUNG	UE37C5100QWXZG
SAMSUNG	UE37C6000RWXZG
SAMSUNG	UE37C6200RSXZG
SAMSUNG	UE37C6700USXXN
SAMSUNG	UE37C6700USXZG
SAMSUNG	UE37C6730USXXN
SAMSUNG	UE37C6730USXZG
SAMSUNG	UE37C6740SSXXN
SAMSUNG	UE37C6740SSXZG
SAMSUNG	UE37C6800USXXN
SAMSUNG	UE37C6800USXZG

SAMSUNG	UE37C6820USXXN
SAMSUNG	UE37C6820USXZG
SAMSUNG	UE40B6000VPXXN
SAMSUNG	UE40B6000VPXZG
SAMSUNG	UE40B7000WPXXN
SAMSUNG	UE40B7000WPXZG
SAMSUNG	UE40B7020WPXXN
SAMSUNG	UE40B7090WPXZG
SAMSUNG	UE40B8000XPXXN
SAMSUNG	UE40B8090XPXZG
SAMSUNG	UE40C5100QWXZG
SAMSUNG	UE40C6000RWXZG
SAMSUNG	UE40C6200RSXZG
SAMSUNG	UE40C6700USXXN
SAMSUNG	UE40C6700USXZG
SAMSUNG	UE40C6710USXXN
SAMSUNG	UE40C6710USXZG
SAMSUNG	UE40C6730USXXN
SAMSUNG	UE40C6730USXZG
SAMSUNG	UE40C6740SSXXN
SAMSUNG	UE40C6740SSXZG
SAMSUNG	UE40C6800USXXN
SAMSUNG	UE40C6800USXZG
SAMSUNG	UE40C6820USXXN
SAMSUNG	UE40C6820USXZG
SAMSUNG	UE40C7700WSXXN
SAMSUNG	UE40C7700WSXZG
SAMSUNG	UE40C8700XSXXN
SAMSUNG	UE40C8790XSXZG
SAMSUNG	UE40D7000
SAMSUNG	UE40D8000
SAMSUNG	UE46B6000VPXXN
SAMSUNG	UE46B6000VPXZG
SAMSUNG	UE46B7000WPXXN
SAMSUNG	UE46B7020WPXXN
SAMSUNG	UE46B7090WPXZG
SAMSUNG	UE46B8000XPXXN
SAMSUNG	UE46B8090XPXZG
SAMSUNG	UE46C5100QWXZG
SAMSUNG	UE46C6000RWXZG
SAMSUNG	UE46C6200RSXZG
SAMSUNG	UE46C6700USXXN
SAMSUNG	UE46C6700USXZG
SAMSUNG	UE46C6710USXXN
SAMSUNG	UE46C6710USXZG
SAMSUNG	UE46C6730USXXN
SAMSUNG	UE46C6730USXZG
SAMSUNG	UE46C6740SSXXN
SAMSUNG	UE46C6740SSXZG
SAMSUNG	UE46C6800USXXN

SAMSUNG	UE46C6800USXZG
SAMSUNG	UE46C6820USXXN
SAMSUNG	UE46C6820USXZG
SAMSUNG	UE46C6900VSXXN
SAMSUNG	UE46C7700WSXXN
SAMSUNG	UE46C7700WSXZG
SAMSUNG	UE46C8700XSXXN
SAMSUNG	UE46C8790XSXZG
SAMSUNG	UE55B7000WPXXN
SAMSUNG	UE55B7020WPXXN
SAMSUNG	UE55B7090WPXZG
SAMSUNG	UE55C6000RWXZG
SAMSUNG	UE55C6200RSXZG
SAMSUNG	UE55C6700USXXN
SAMSUNG	UE55C6700USXZG
SAMSUNG	UE55C6740SSXXN
SAMSUNG	UE55C6740SSXZG
SAMSUNG	UE55C6900VSXXN
SAMSUNG	UE55C7700WSXXN
SAMSUNG	UE55C7700WSXZG
SAMSUNG	UE55C8700XSXXN
SAMSUNG	UE55C8790XSXZG
SAMSUNG	UE65C8700XSXXN
SAMSUNG	UE65C8790XSXZG
SHARP	32PF9631D
SHARP	LC-19LE320E
SHARP	LC-22LE320E
SHARP	LC-26LE320E
SHARP	LC-32LE320E
SHARP	LC-32LE705E
SHARP	LC-32LU705E
SHARP	LC-32LX705E
SHARP	LC32RD2S
SHARP	LC37AD5S
SHARP	LC-37LE320E
SHARP	LC-37XD1E
SHARP	LC-40LE705E
SHARP	LC-40LE810E
SHARP	LC-40LE812E
SHARP	LC-40LE820E
SHARP	LC-40LE822E
SHARP	LC-40LU705E
SHARP	LC-40LU820E
SHARP	LC-40LU822E
SHARP	LC-40LX705E
SHARP	LC-40LX810E
SHARP	LC-40LX812E
SHARP	LC-42LE320E
SHARP	LC42WD1S
SHARP	LC-46LE705E

SHARP	LC-46LE810E
SHARP	LC-46LE812E
SHARP	LC-46LE820E
SHARP	LC-46LE822E
SHARP	LC-46LU705E
SHARP	LC-46LU820E
SHARP	LC-46LU822E
SHARP	LC-46LX705E
SHARP	LC-46LX810E
SHARP	LC-46LX812E
SHARP	LC-46XL1E
SHARP	LC-52LE705E
SHARP	LC-52LE820E
SHARP	LC-52LE822E
SHARP	LC-52XD1K
SONY	KDL19S5700E
SONY	KDL19S5710E
SONY	KDL19S5720E
SONY	KDL19S5730E
SONY	KDL-22E5300
SONY	KDL-22E5300
SONY	KDL22E5300E
SONY	KDL-22E5310
SONY	KDL22E5310E
SONY	KDL22EX302BAEP
SONY	KDL-22EX325
SONY	KDL-24EX325
SONY	KDL26EX302AEP
SONY	KDL-26EX325
SONY	KDL26S5550E
SONY	KDL32BX300AEP
SONY	KDL-32BX320
SONY	KDL32BX400AEP
SONY	KDL-32CX523
SONY	KDL-32CX525
SONY	KDL-32E5500
SONY	KDL32E5500E
SONY	KDL-32E5510
SONY	KDL32E5510E
SONY	KDL-32E5520
SONY	KDL32E5520E
SONY	KDL32EX302AEP
SONY	KDL32EX402AEP
SONY	KDL32EX40B
SONY	KDL32EX40BAEP
SONY	KDL-32EX425
SONY	KDL32EX500
SONY	KDL32EX500AEP
SONY	KDL-32EX505
SONY	KDL32EX505AEP

SONY	KDL-32EX508
SONY	KDL32EX508AEP
SONY	KDL-32EX525
SONY	KDL-32EX605
SONY	KDL32EX605AEP
SONY	KDL32EX700
SONY	KDL-32EX705
SONY	KDL32EX705AEP
SONY	KDL-32EX706
SONY	KDL32EX706AEP
SONY	KDL-32EX707
SONY	KDL32EX707AEP
SONY	KDL-32EX709
SONY	KDL32EX709AEP
SONY	KDL-32EX725
SONY	KDL-32EX726
SONY	KDL-32EX727
SONY	KDL-32EX728
SONY	KDL-32EX729
SONY	KDL32NX500AEP
SONY	KDL-32P3550
SONY	KDL32S5550E
SONY	KDL32S5650E
SONY	KDL-32V5500
SONY	KDL32V5500E
SONY	KDL-32V5610
SONY	KDL-32V5800
SONY	KDL32V5800AEP
SONY	KDL-32V5810
SONY	KDL-32W5500
SONY	KDL32W5500E
SONY	KDL-32W5710
SONY	KDL-32W5720
SONY	KDL-32W5730
SONY	KDL-32W5740
SONY	KDL-32W5800
SONY	KDL32W5800AEP
SONY	KDL-32W5810
SONY	KDL32W5810AEP
SONY	KDL-32W5820
SONY	KDL32W5820AEP
SONY	KDL-32W5830
SONY	KDL32W5830AEP
SONY	KDL-32W5840
SONY	KDL32W5840AEP
SONY	KDL37EX402AEP
SONY	KDL37EX500
SONY	KDL37EX500AEP
SONY	KDL-37EX505
SONY	KDL37EX505AEP

SONY	KDL-37EX525
SONY	KDL-37EX725
SONY	KDL37S5650E
SONY	KDL-37V5500
SONY	KDL-37V5610
SONY	KDL-37V5800
SONY	KDL37V5800AEP
SONY	KDL-37V5810
SONY	KDL37V5810AEP
SONY	KDL-37W5500
SONY	KDL37W5500E
SONY	KDL-37W5710
SONY	KDL-37W5720
SONY	KDL-37W5730
SONY	KDL-37W5740
SONY	KDL-37W5800
SONY	KDL37W5800AEP
SONY	KDL-37W5810
SONY	KDL37W5810AEP
SONY	KDL-37W5820
SONY	KDL37W5820AEP
SONY	KDL-37W5830
SONY	KDL37W5830AEP
SONY	KDL-37W5840
SONY	KDL37W5840AEP
SONY	KDL-40 EX508
SONY	KDL-40 EX525
SONY	KDL-40 EX605
SONY	KDL-40 EX705
SONY	KDL-40 EX706
SONY	KDL-40 EX707
SONY	KDL-40 EX708
SONY	KDL-40 EX709
SONY	KDL-40 EX725
SONY	KDL-40 EX726
SONY	KDL-40 EX727
SONY	KDL-40 EX728
SONY	KDL-40 EX729
SONY	KDL-4000W
SONY	KDL40BX400AEP
SONY	KDL-40CX525
SONY	KDL-40E5500
SONY	KDL40E5500E
SONY	KDL-40E5510
SONY	KDL40E5510E
SONY	KDL-40E5520
SONY	KDL40E5520E
SONY	KDL40EX402AEP
SONY	KDL40EX40B
SONY	KDL40EX40BAEP



SONY	KDL40EX500
SONY	KDL40EX500AEP
SONY	KDL-40EX505
SONY	KDL40EX505AEP
SONY	KDL40EX508AEP
SONY	KDL40EX605AEP
SONY	KDL40EX700
SONY	KDL40EX705AEP
SONY	KDL40EX706AEP
SONY	KDL40EX707AEP
SONY	KDL40EX708AEP
SONY	KDL40EX709AEP
SONY	KDL40HX700
SONY	KDL40HX705AEP
SONY	KDL-40HX725
SONY	KDL40HX800
SONY	KDL-40HX805
SONY	KDL40HX805AEP
SONY	KDL-40HX905
SONY	KDL40LX900
SONY	KDL-40LX905
SONY	KDL40NX500AEP
SONY	KDL40NX700F
SONY	KDL40NX700WF
SONY	KDL-40NX705
SONY	KDL40NX705AEP
SONY	KDL40NX705WAEP
SONY	KDL-40NX715
SONY	KDL-40NX725
SONY	KDL40NX800F
SONY	KDL-40NX805
SONY	KDL40NX805AEP
SONY	KDL40S5650E
SONY	KDL-40V5500
SONY	KDL40V5500E
SONY	KDL-40V5610
SONY	KDL-40V5800
SONY	KDL40V5800AEP
SONY	KDL-40V5810
SONY	KDL-40Vxxx
SONY	KDL-40W5500
SONY	KDL40W5500E
SONY	KDL-40W5710
SONY	KDL-40W5720
SONY	KDL-40W5730
SONY	KDL-40W5740
SONY	KDL-40W5800
SONY	KDL40W5800AEP
SONY	KDL-40W5810
SONY	KDL40W5810AEP

SONY	KDL-40W5820
SONY	KDL40W5820AEP
SONY	KDL-40W5830
SONY	KDL40W5830AEP
SONY	KDL-40W5840
SONY	KDL40W5840AEP
SONY	KDL-40WE5B
SONY	KDL40WE5BAEP
SONY	KDL-40WE5W
SONY	KDL40WE5WAEP
SONY	KDL40Z5500AEP
SONY	KDL-40Z5800
SONY	KDL40Z5800AEP
SONY	KDL-40Z5810
SONY	KDL-46 EX705
SONY	KDL-46 EX706
SONY	KDL-46 EX707
SONY	KDL-46 EX708
SONY	KDL-46 EX709
SONY	KDL-46 EX725
SONY	KDL-46 EX726
SONY	KDL-46 EX727
SONY	KDL-46 EX728
SONY	KDL-46 EX729
SONY	KDL-46CX525
SONY	KDL46EX402AEP
SONY	KDL46EX500
SONY	KDL-46EX505
SONY	KDL46EX505AEP
SONY	KDL-46EX525
SONY	KDL46EX700
SONY	KDL46EX705AEP
SONY	KDL46EX706AEP
SONY	KDL46EX707AEP
SONY	KDL46EX708AEP
SONY	KDL46EX709AEP
SONY	KDL46HX700
SONY	KDL-46HX705
SONY	KDL46HX705AEP
SONY	KDL-46HX725
SONY	KDL46HX800
SONY	KDL-46HX805
SONY	KDL46HX805AEP
SONY	KDL-46HX825
SONY	KDL46HX900
SONY	KDL-46HX925
SONY	KDL46NX700F
SONY	KDL46NX700WF
SONY	KDL-46NX705
SONY	KDL46NX705AEP

SONY	KDL46NX705WAEP
SONY	KDL-46NX715
SONY	KDL-46NX725
SONY	KDL-46V5500
SONY	KDL46V5500E
SONY	KDL-46V5800
SONY	KDL46V5800AEP
SONY	KDL-46V5810
SONY	KDL-46W5500
SONY	KDL46W5500E
SONY	KDL-46W5710
SONY	KDL-46W5720
SONY	KDL-46W5730
SONY	KDL-46W5740
SONY	KDL-46W5800
SONY	KDL46W5800AEP
SONY	KDL-46W5810
SONY	KDL-46W5820
SONY	KDL46W5820AEP
SONY	KDL-46W5830
SONY	KDL-46W5840
SONY	KDL-46WE5B
SONY	KDL46WE5BAEP
SONY	KDL-46WE5W
SONY	KDL-46Z5800
SONY	KDL46Z5800AEP
SONY	KDL52EX700
SONY	KDL-52EX705
SONY	KDL52EX705AEP
SONY	KDL52HX900
SONY	KDL-52HX905
SONY	KDL52LX900
SONY	KDL-52LX905
SONY	KDL52NX800F
SONY	KDL-52NX805
SONY	KDL52NX805AEP
SONY	KDL-52NX815
SONY	KDL-52V5500
SONY	KDL-52V5800
SONY	KDL52V5800AEP
SONY	KDL-52V5810
SONY	KDL-52W5500
SONY	KDL-52W5500
SONY	KDL52W5500E
SONY	KDL-52W5800
SONY	KDL52W5800AEP
SONY	KDL-52W5810
SONY	KDL52Z5800AEP
SONY	KDL55EX500
SONY	KDL-55EX505

SONY	KDL55EX505AEP
SONY	KDL-55EX725
SONY	KDL-55HX825
SONY	KDL-55HX925
SONY	KDL-55NX725
SONY	KDL60EX700
SONY	KDL-60EX705
SONY	KDL60EX705AEP
SONY	KDL60LX900
SONY	KDL-60LX905
SONY	KDL-60NX725
SONY	KDL-65HX925
SONY	KDL-xxD2600
SONY	KDL-xxD2700
SONY	KDL-xxD2800
SONY	KDL-xxD3000
SONY	KDL-xxD3400
SONY	KDL-xxD3500
SONY	KDL-xxD3600
SONY	KDL-xxS2800
SONY	KDL-xxS3000
SONY	KDL-xxT2600
SONY	KDL-xxT2800
SONY	KDL-xxT3000
SONY	KDL-xxV3000
SONY	KDL-xxW3000
SONY	KDL-xxX3000
SONY	KDL-xxX3500
TCL	32FT7563
TCL	DTL42E9FQ
Technisat	MULTYVISION( BILDSCHIRMDIAGONALE—101, ZOLL-40)
Technisat	MULTYVISION( BILDSCHIRMDIAGONALE—80, ZOLL-32)
Technisat	TECHNILINE 32 HD CI+
Technisat	TechniLine 32 HD mit CI+
Technisat	TECHNILINE 40 HD
Technisat	TechniLine 40 HD mit CI+
TOSHIBA	40TL968
TPV	MT5366
Vestel	S7000 V0.1.3 HD DVB-S
Vestel	T4500 v2.6 HD DVB-T v5.7 DVB-S